XCU Fusion
316L stainless-steel dual imager camera
Quick Start Guide

Find additional manuals, the datasheet, the EU Declaration of Conformity, and the latest firmware for this product at:

siqura.com/downloads/software

SIQURA

Unpack

- 1x Camera unit
- 1x Quick Start Guide

Note 1: Subject to modification. Actual product and accessories may differ in appearance.

Mount

Wall mounted XCU Fusion

XCU Fusion ceiling mounted on XCUCM01

XCU Fusion ceiling mounted on XCUCM02

XCU Fusion wall/pole mounted on XCUCM02

Note 2: For detailed mounting instructions, download the installation manual.
*Note 3*: The silica gel packet inside the camera must be replaced if the camera has been opened.

Connect and point

*Connect to network*

*Connect to power (see warning below)*

Pinning power connector

⚠️ **CAUTION:** MAKE SURE THAT THE POWER SUPPLY VOLTAGE MATCHES THE VOLTAGE RATING OF THE XCU FUSION. CHECK THE PRODUCT LABEL TO DETERMINE THE VOLTAGE REQUIRED FOR PROPER OPERATION. DO **NOT** CONNECT A 24 VAC MODEL TO A 115 VAC OR 230 VAC POWER SUPPLY!

Assign IP address with DHCP...


## .. or assign IP address without DHCP

Install Device Manager

Note 4: On the Siqura website, choose SDM2 2.5.1 installer or higher.

---

siqura.com

Change network settings

Upgrade firmware

IMPORTANT: FOR BEST PERFORMANCE AND NETWORK SECURITY, MAKE SURE TO DOWNLOAD THE LATEST FIRMWARE VERSION FROM SIQURA.COM. THEN, UPGRADE THE FIRMWARE IN THE DEVICE MANAGER (SEE BELOW).


Create Admin account

IMPORTANT: MAKE SURE YOU CREATE AN ADMIN ACCOUNT WHEN YOU OPEN THE WEB INTERFACE FOR THE FIRST TIME. TO KEEP THE ACCOUNT SAFE, SET A STRONG, COMPLEX PASSWORD. THIS HELPS TO PREVENT UNAUTHORISED ACCESS.

Set a strong password!

qwerty1234 ✖

x6W@oM0a!9#F ✔

View live video via browser

Change image settings

View video stream in video player

rtsp://10.0.231.156/VideoInput/1/h264/1

camera IP address

video input number
1 = optical input
2 = thermal input

media type

video encoder number