

# BL2002M1-EI

## 2MP Network Bullet Camera

### Quick Start Guide




Find additional manuals, the datasheet, the EU Declaration of Conformity, and the latest firmware for this product at:

[Siqura.com/downloads/software](http://Siqura.com/downloads/software)



### Unpack



**Note 1:** Subject to modification. Actual product and accessories may differ in appearance.

### Installation Notices




**CAUTION:**  
 INSTALLATION SHALL BE PERFORMED BY QUALIFIED PERSONNEL ONLY. INSTALLATION SHALL BE IN ACCORDANCE WITH LOCAL PROCEDURES. INSTALLATION WITH POE SHALL BE IN UNEXPOSED NETWORKS. BATTERY REPLACEMENT SHALL NOT BE APPLIED IN VIEW OF THE RISK OF EXPLOSION.  
 IF YOU USE AN EXTERNAL POWER SUPPLY, CONTACT SIQURA TO MAKE SURE THAT THE POWER SUPPLY HAS THE PROPER POWER SPECIFICATIONS. MAKE SURE THAT THE POWER SUPPLY COMPLIES WITH LPS REQUIREMENTS.



**NOTE:**  
 IT IS NOT RECOMMENDED TO CONTINUOUSLY (24/7) RECORD WITH THE MICRO SD CARD, AS THE CAMERA MAY NOT SUPPORT LONG-TERM CONTINUOUS DATA READ/WRITE. CONTACT THE MANUFACTURER OF THE MICRO SD CARD FOR INFORMATION REGARDING THE RELIABILITY AND THE LIFE EXPECTANCY.

### Connectors




### Connector Definition


No.	Connector	Definition
1	Alarm I/O	Alarm I/O connection
2	Audio	Audio Line in/Out
3	RJ-45 Port (Contact Siqura for a compatible PoE injector.)	For network and PoE connections
4	Power (DC12V)	Power connection
5	SD Card Slot	Insert the SD card into the card slot to store videos and snapshots. Do not remove the SD card when the camera is powered on.
6	Reset Button	Press the button with a proper tool for at least 20 seconds to restore the system.

Table 1 Connector definition

### Cabling through Junction Box



### Pan/Tilt/Rotate



## Mounting



Wall/Pole Mount




Ceiling Mount




**NOTE:**  
OTHER THAN MOUNTING ABOVE, OTHER MOUNTING MAY CAUSE POTENTIAL WATER LEAKAGE AT CAMERA, WHICH IS NOT INCLUDED IN WARRANTY.

## Accessing the camera - DHCP Server



## Accessing the camera – Fixed IP address



## Auto detect with SDM2

[Siqura.com/downloads/software](https://www.siqura.com/downloads/software)

SDM2-vx.xx-setup.zip

## 1<sup>st</sup> time camera login

Set a strong password

qwer1234 ❌

x6W@oM0a!9#F ✅

## Browser-based Viewer

