Siqura BL1002F4-EI
3 MP Intelligent IP bullet camera with IR
Quick Start Guide

Find additional manuals for this Siqura product at: www.siqura.com/support-files

TKH GROUP **SIQURA®**

Unpack

Note: Subject to modification. Actual product and accessories may differ in appearance.

Connect

RJ-45
802.3af PoE

12 Vdc

IP66 ingress protection (optional)

Mount and point

1. Fasten
2. Pan
3. Tilt
4. Rotate

Note: For mounting instructions for pole, corner or box mount, see respective manuals.

Insert Micro SD card / Reset


Reset button

Micro SD/SDHC/SDXC
(up to 128 GB)

Reset button: Press and hold for 10 sec. when powering on or rebooting.
Warning: Restores factory default settings, including IP address, user name and password!

Use DHCP server

DHCP: ☑

Network switch

IP = 10.x.y.z

IP = 10.x.y.z

IP = 10.x.y.z

DHCP

Use fixed IP address

DHCP: ☑

30 s

IP = 192.168.1.x

2 ~ 253

Network switch

IP = 192.168.1.x

DHCP

Note: Use Siqura Device Manager (see next) to discover the camera on the network.

TKH GROUP member of the TKH Group

Install Siqura Device Manager

Important: *Siqura 1002 series cameras require Siqura Device Manager version 1.8.1 or later.*
*Replace an existing, older installation of this tool on your PC, if necessary!*

Change IP address via Siqura Device Manager


Open web interface via Siqura Device Manager

View live video

Adjust video

Set up security

Open access

Installer/Technician — Do *not* set a password

Administrator / End User — Set a (strong) password